MICRO MOTOR

USER'S MANUAL









Read all safety instructions throughly before operating the unit. Keep this user's manual in a safe place for future reference.

1.NAIL FILING MACHINE is an idea filing tool set for nail decoration. It has forward and reverse dual direction-rotations for left- or right-handed nail technicians, The allowable rotation speed can be adjustable speed, quiet & smooth operation handpiece with a flexible extension, which is convenient to use for finishing the nails.

2.Application

It is widely used for forming, buffing, sculptured and pierce drilling etc of metal, wood, glass, leather products, ceramics, plastic and other material objects.

3. How To Use

- (1).Insert the handpiece flex plug into the power output socket on the main control machine.
- (2).Loose the chuck by left-turning the Middle part on the hand-piece and insert/change the Bit and tighten the chuck by right-turning the Middle part on the hand-piece.
- (3). Plug the controller into appropriate power source.
- (4). Choose the mode "FORWARD" or "REVERSE" direction, and then open the total power switch to start the machine.

(5). Rotate the feed rate knob that you need by sliding the speed control handle.

Operation Procedure

Mounting and removing bur

Originally \emptyset 2.35mm blank bar is attached but any bit can be mounted as you like. Please the collet suitable for the chosen bit.

- (1). Holding Handpiece in hand, turn Set Ring fully toward "R" direction. Taking out blank bar, Put your bit into the bottom of collet.
- (2). Return the Set Ring to "S" direction, where collet is secured.
- (3). Make it sure with fingers that your bit and collet can rotate. When ensuring it, Please take care of bit edge not to hurt your finger.



